


Com 107 Recital Hall A/V System

Contact Shannon 867-5896 for key authorization.



CAUTION! Clear all furniture and shut the door before lowering the screen.

To watch a DVD: Press the *Display Power button* for two seconds. Let go and it will start flashing, indicating the projector has been powered and is warming up. The projection screen controls can be found behind the stage. Press the *DVD button* above the blue DVD light. The room audio switch should be down. You can control the volume with the Master Volume Knob. If needed, the remote controls are in the Info Office, room 302A.

To watch a VHS: Press the *Display Power button* for two seconds. Let go and it will start flashing, indicating the projector has been powered and is warming up. The projection screen controls can be found behind the stage. Press the *VCR/TV button* above the blue VCR/TV light. Change the VCR to L1 in order to watch a VHS tape. The room audio switch should be down. You can control the volume with the Master Volume Knob. If needed the remote controls are in the Info Office, room 302A.

To listen to music: Insert the CD into the DVD player and press the *DVD/CD button* above the blue light. Or insert the cassette into the cassette player and press the button beneath the cassette light. The Room Audio Switch should be down. Control the volume with the Master Volume.

To show a computer: Connect the RGB cable from your computer to the computer input. To play sound from your computer also plug in a mini 1/8" audio cable into the Computer Audio Input. Press the *Display Power button* for two seconds. Let go and it will start flashing, indicating the projector has been powered and is warming up. The projection screen controls can be found behind the stage. Press the *Computer button* above the blue Computer light. The room audio switch should be down. You can control the volume with the Master Volume Knob.

WHEN YOU ARE FINISHED: Press Display Power for two seconds. It will start flashing - indicating it is powering down. All other equipment will go to sleep in a few minutes. **Lock Up!**

For technical assistance, call Electronic Media at 867-6270
or Media Loan at 867-6253.